


Protect your  
**Family  
First**<sup>®</sup>

**PRODUCT MANUAL  
FF9VWA**



**MAIN FEATURES:**

- 9V battery powered
- Loud, audible alarm
- Fully automatic operation

**IMPORTANT:** This manual contains important information about the installation and operation of your water leak alarm. Please read carefully before installation and keep for future reference. Please ensure that this leaflet remains in the household where the alarm is installed.

**WARNING:** This water leak alarm is designed to alert you to the presence of water. It cannot prevent flooding. The ultimate responsibility for flood protection rests with you. This responsibility includes maintenance of appliances that use water.

DO NOT try to disassemble this alarm, as it may damage or impede the operation. No user serviceable parts inside. The warranty will become void if misuse or abuse is apparent.

**FOR MORE INFORMATION AND FAQ PLEASE  
VISIT [WWW.FAMILY-FIRST.COM.AU](http://WWW.FAMILY-FIRST.COM.AU)**



31 Dunlop Road Mulgrave Victoria 3170  
Ph 03 9538 9200 Fax 03 9538 9299  
[sales@masterdistributors.com.au](mailto:sales@masterdistributors.com.au)  
[www.masterdistributors.com.au](http://www.masterdistributors.com.au)  
**26092014**

**WHERE TO INSTALL YOUR ALARM**

The water leak alarm is suitable for installation in any potential flood spot. This includes next to washing machines, sinks, dishwashers, water heaters, bathrooms, basements, boats, sump pumps, garages etc.

**TO USE**

The water leak alarm is armed when the battery is installed. To do so, use a coin to unscrew the battery door and attach a 9V battery to the appropriate leads in the battery component. Once inserted re-assemble the unit.

Next, place the water leak alarm on the floor in any area of your home that has the potential to leak. If the water leak alarm detects water a loud alarm will sound.

DO NOT place the alarm on any metal or other conductive surface. This may cause the alarm to sound without water present.

**TO DISARM**

Simply remove the water alarm from the water and remove the battery. Allow the unit to dry completely before re-using.

**BATTERY/REPLACEMENT**

When the battery is getting low the alarm will chirp once every 30 seconds. To change the battery please see under the 'TO USE' instructions.

**TO TEST**

To test the water leak alarm for correct operation place the alarm on a damp cloth. If the alarm sounds then it is operating normally.

**2 YEAR WARRANTY**

The water leak alarm is warranted to be free from defects in materials and workmanship for two (2) years from the date of purchase and is not transferable under normal use. The warranty does not cover natural disasters such as fire, flood, hurricanes and tornadoes. The warranty only applies if the water leak alarm is installed in accordance with local regulations, is used in the normal way and is serviced regularly. The warranty is also conditional on the water leak alarm not being modified or subject to attempted repairs or contamination. The warranty excludes the battery, incidental and consequential damages. Your statutory rights as a consumer are in no way compromised by this warranty. Master Distributors Pty Ltd agrees to repair or replace, at it's option, any defective water leak alarm provided it is returned personally or by prepaid delivery with a copy of proof of purchase. This warranty does not cover damages resulting from lack of reasonable care of the product. *Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.* Subject to those non-excluded rights and provisions and the above warranty, Master Distributors Pty Ltd will not be liable for injury to persons, damage to property, or for any direct or indirect or consequential damage as a result of negligence or fault on the part of Master Distributors Pty Ltd or it's servants, agents, suppliers and contractors or otherwise arising out of or resulting from, whether directly or indirectly, the use, installation or maintenance of the water leak alarm and any warranties or representations are excluded unless given by Master Distributors Pty Ltd in writing. Please leave this document, or a copy, for the end user.